

Replaces all previous versions

Effective 1st July 2010

RACKING ACCESSORIES



Complies with Australian Standard AS-4084

Barrel Chocks




Barrel Chocks are used when barrels or drums are to be stored on Keylock Beams. They prevent the barrel from rolling along the beam.

The Barrel Chocks are fitted over the front beam or both front and rear beams, but are not fixed.

Part Number	Descriptions
# 028530	BARREL CHOCK K6 DBL ORGE
# 028531	BARREL CHOCK K6 SGL ORGE

Upright Protector



The upright protector stands immediately in front of the upright to protect it from damage by forklifts.

It is anchored through impact absorbing rubber blocks.

Part Number	Descriptions
# 028899	RUBBER BLOCK K6 UPR PROT BLK
# 028900	UPRIGHT PROTECTOR K6 90 ORGE

Pallet Support Bars



Supported at each end by the beams, Pallet Support Bars provide a secondary support member for pallet racking.

The Pallet Support Bar is designed to have its top surface approximately flush with the beams.

Part Number	Descriptions
# 023107	PSB K6 50 TYPE A 838FRM ORGE
# 023113	PSB K6 50 TYPE A 1219FRM ORGE

SmartGuard



When it comes to rack protection and improving workplace safety SmartGuard is the lowest cost solution on the market.

There are no installation costs, no floor damage upon impact, and replacement costs are low.

Part Number	Descriptions
# 4197	SMARTGUARD K6 90 &MK3 UPR ORGE
# 4196	SMARTGUARD K6 90 CLIP PGAL
# 4198	SMARTGUARD MK3 SMH&E CLIP PGAL

Please email to sales@spacepac.com.au for current pricing

Our policy of constant product improvement may lead to changes to specifications/prices without notice.

Replaces all previous versions

Effective 1st July 2010

RACKING ACCESSORIES



Complies with Australian Standard AS-4084

Column Guard

The column guard is bolted to the floor in front of the uprights to a height of 360mm providing protection from forklifts to the bottom portion of the upright. As it is not connected to the upright it takes all impact.

Part Number	Descriptions
# BDB	V pallet racking leg guard Incl 4x12mm anchors

Rack Inspection Kits

The user guides and inspection forms allow you to keep accurate records that comply with AS4084.

The Rack Inspection kit is suitable for most types of pallet racking.

The kit comes complete with the following:

- Non Standard Beam Deflection Gauge
- Standard Beam Deflection Gauge
- Upright Inspection Gauge
- Upright Assessment Module
- Deflection Assessment Module
- Inspection Forms Record Book
- User Guide

Part Number	Descriptions
# 2455	RACK INSPECTION KIT COMPLETE
# 2459	HORIZONTAL DEFLECTION MODULE
# 2460	VERTICAL DEFLECTION MODULE
# 2465	RACK INSPECTION GAUGE KIT
# 2466	RACK INSPECTION KIT USER GUIDE

Safety Signs

Safety Signs are crucial items in rack safety.

These signs are instrumental in safe use of racking as outlined in Australian Standard AS4084.

SAFE WORKING LOAD SIGNS

Includes 4 x 18mm S/Adh Labels for Load Capacity.

This sign is a loading notice conforming to AS 4084-93 Steel Storage Racking. To assist in ensuring the rack is loaded within recommended safety limits. It should be prominently displayed within the operating area of the racking.


Part Number	Descriptions
# SPPRS01	Safe working load racking sign 450w×450h-Metal
# SPRRS02	Maintenance of racking sign 450w×450h- Metal
# SPRRS03	Forklift safety sign: Forklift in use 450w×300h-Metal

MAINTENANCE SIGN

This sign contains the basic safety rules to assist in ensuring a safe working environment for the racking systems. It should be prominently displayed within the operating area of the racking.

FORKLIFT SIGN

indicate pedestrian exclusion zones and forklift operating areas and forklift exclusion zones for pedestrians.



Our policy of constant product improvement may lead to changes to specifications/prices without notice.

Please email to sales@spacepac.com.au for current pricing